


Note:

This document is applicable when the encoder is installed directly on the spindle motor.

In this example, only one spindle orientation position.



Diagram

1: Parameter setting.

- F0-01: 1 (FVC mode, close loop control)
- F0-10: Maximum frequency
- F0-12: Upper limit frequency
- F1-01: Motor rated power
- F1-02: Motor rated voltage
- F1-03: Motor rated current
- F1-04: Motor rated frequency
- F1-05: Motor rated speed
- F1-27: Encoder line number
- F1-28: 0, Encoder is ABZ incremental type, PG card is PG-DIF

2: Self-learning

F1-37: 2

After successful learning, enter no-load operation and observe the operation status. The motor runs smoothly, enter the next step parameter setting. If the motor is not running smoothly, re-check the parameters before self-learning and repeat self-learning till motor runs smoothly.

3: Function parameters setting

F0-02:	1	Terminal command channel
F0-03:	2	Main frequency source AI1
F4-00:	01	X1 is FWD run
F4-01:	65	X2 is spindle orientation
F4-02:	9	X3 Alarm reset
F4-13:	-10	AI1 minimum input
F4-14:	-100%	AI2 minimum input corresponding setup
F4-15:	10	AI1 maximum input
F4-16:	100%	AI2 maximum input corresponding setup
F5-00:	1	FM as switch type output
F5-01:	15	Drive OK
F5-02:	2	Alarm output (Relay type output)
F5-04:	21	Orientation OK
A4-01:	2	Angular orientation mode
A4-20:	---	Orientation Angle
A4-21:	0	Angle source is A4-20

Note:

When set the orientation angle A4-20, please adjust the spindle to the target position, and check the value of u1-02, then store it in A4-20, then take this position as the target position when spindle orientation DI be active.